Leveling the 6m antennas

Dick Plambeck, revision A, 6 Feb 2006

Tiltmeters

A Schaevitz model LSOC-1° inclinometer is installed on the azimuth platform of each 6m antenna usually near the stowpin. Usually the inclinometer is covered with a sheet metal box.



The Bendix connector on the inclinometer is wired to the tilt1 input of the a/d mux board in the cabin, as given in the table below. Raising the right side of the tiltmeter increases the a/d reading. The tilt is given in arcminutes on the BIMA drives rtd screen.

Bendix	D9	signal
А	1	+15 V pwr
В	6, 3	Pwr, signal gnd
С	2	-15 V pwr
D	7	Tilt out, $\pm 5V = \pm 1$ degree

Converting tilts to leg errors

The height of the west leg is fixed. Designate the height of the north and south legs as $N = W + \Delta N$, $S = W + \Delta S$. If we express the tilt as a function of azimuth as:

$$t(\phi) = A \cos(\phi) + B \sin(\phi) + C$$

Where

$$A = (\Delta N + \Delta S) / 2d_1,$$

$$B = (\Delta S - \Delta N) / d_2$$



and C is a constant offset term. One can derive A and B from a least squares fit to the tilt vs. azimuth, or more crudely, from the tilts at azimuths of 0, 90, 180, and 270 degrees:

A = 0.5 (t(0) - t(180))B = 0.5 (t(90) - t(270)).

Thus, if the tilt is more positive at φ =90 than at φ =270, the south leg is higher than the north leg. Solving for ΔN and ΔS in inches, one finds:

 ΔN (inches) = 0.024 A (arcmin) – 0.014 B (arcmin) ΔS (inches) = 0.024 A (arcmin) + 0.014 B (arcmin)

One must *remove* these errors in order to level the antenna; that is, if $\Delta N = 0.1$ inch, one must *shorten* the N leg by 0.1 inch. The adjustment screws have 4 threads per inch, so one full turn changes the height by 0.25 inch.

Adjusting the feet

- 1. Loosen tiedown nuts at the 4 corners of the base.
- 2. Jack up the N or S corner of the base to take the weight off the foot. Be sure to insert the jack under the reinforcing plate see diagram below.
- 3. Use special wrench to turn adjustment ring on the foot. Turning the ring CW unscrews the support screw from the base, thus raises the base.
- 4. Lower the jack; adjust other leg; remeasure tilt.
- 5. When finished, tighten the tiedowns at the 4 corners of the base.



